


# SerialSniffer Hardware Adapter

SerialSniffer is designed to record the data which is transferred on a serial link between two devices. The first possibility is to open the serial link and connect SerialSniffer between the two devices :




external device #1

SerialSniffer

external device #2


The second possibility is to connect SerialSniffer "parallel" to the existing serial link using a hardware adapter. This solution prevents the serial connection from being influenced by SerialSniffer



external device #1

SerialSniffer

external device #2



The schematic diagram can be found at the left. This is only a proposal to build an adapter on your own. A professional one (named "V.24 tester") can be found on our website.

more infos :  
- <http://www.flache.de>  
- [shareware@flache.de](mailto:shareware@flache.de)  
last changed : 09.10.2002